

# Head Strong Instructions




**ATHENA'S**  
HOME NOVELTIES

SKU 3506

Experience the power of a big wand massager with this petite, lightweight wand. Head Strong is made of premium grade silicone. The velvety soft, textured handle is topped with a flexible neck and smooth rounded head. The high strength motor provides exceptional power. 8 speeds and 20 modes of vibration will keep you coming and going! Apply your favorite massage oil to the skin and let Head Strong soothe your sore, tired muscles. Apply your favorite lube and release stress and tension with an orgasmic explosion. Head Strong comes with a storage bag to keep it lint free and ready for action when you are. Head Strong is also waterproof! Enjoy it in tub or shower. Colors may vary.

## Features :

- 1 year warranty
- Total length: 7.8 inches
- Width: 1.68 inches at widest point
- Waterproof and submersible
- Storage bag included
- Made from smooth silicone and ABS Plastic trim
- Not for use with silicone lubricants
- Phthalate free
- Rechargeable: USB charge cord included
- Charge time: 90 minutes
- Run time low speeds: 90 minutes



## Cleaning

Clean before and after use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

## Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). You can find additional lubrication options on our web site or in our catalog. Do not use this vibe with silicone lubricants.

Follow these simple steps to help extend the life cycle of your items

Do not store products near extreme cold or heat.

Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.

Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.

Store in a cool dry location.

## Caution

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain. Do not massage around chest or throat.

## Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given.

Effective February 1, 2021, this motorized product is guaranteed for 1 year for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item. All defective product returns must be accompanied by a pre-authorization number.

If the return is authorized within 30 days of the customer's or distributor's receipt, AHN will cover the cost of shipping the defective item back to AHN. If the return authorization is issued after the 30 days, the customer and/or the distributor will be responsible for the cost of shipping the defective item back to AHN.




**ATHENA'S**  
HOME NOVELTIES

©December 2021  
Athena's Home Novelties, Inc.  
Woonsocket RI 02895  
www.athenashn.com  
1-877-ATHENAS


## Operating

**ON/OFF:** Tap the On/Off bottom button for 2 seconds to start and initiate the 1st speed and pulse, tap for 2 seconds to stop. The buttons will glow when On. Continue to tap the buttons to adjust speed and pulse of the toy.

**Speed and Pulsation:** Tap the top for the 7 additional settings of speeds. Each press will cycle to the next speed. Tap the middle button for the 19 additional settings of pulsations. Each press will cycle to the next vibration level of intensity.



## Charging



Comes partially charged. Fully charge upon opening. Gently insert the input plug at the base of the massager and connect the USB output plug to the USB port of your computer or other power source.

LED lights will glow while charging and stop glowing when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend to not over charge for long periods of time. We recommend fully charging your product once every 3 months.

Only use the charging cord provided in this package with the product or a manufacturer approved replacement cord.

Charge time: 90 minutes  
Run time low speeds: 90 minutes