
Incognito Instructions



SKU 3515

No one will ever know when you go Incognito. This stylish and thin polished metal vibe resembles an upscale pen or stylus. The one touch button brings the whisper quiet motor to life. Experience 5 vibrating speeds and functions. With its elegant black chrome finish, this little secret weapon can even be worn around your neck on your favorite chain. Incognito is waterproof and submersible so you can enjoy discreet pleasure in the tub or shower. Lightweight and perfect for travel you can vibe anytime!



Cleaning and storage

Clean before and after use. Dry completely. For best results we recommend using Athena's (antibacterial) Mighty Tidy Toy Cleaner (SKU MTT-1235 4 oz. or SKU MTT-2762 8 oz.)

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer SKU 5701. You can find additional lubrication options on our web site or in our catalog.

Follow these simple steps to help extend the life cycle of your items

Do not store products near extreme cold or heat.

Do not store your adult toys in a manner where they are touching. Keep them separated to avoid melting or discoloring.

Do not place lotion bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and the finish on your furniture.

Caution

For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given. Effective February 1, 2021, this motorized product is guaranteed for 5 years for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com for instructions to send back your item.

All defective product returns must be accompanied by a pre-authorization number. If product arrives broken or breaks within 30 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's, Athena's is responsible for the shipping of the replacement. If this item breaks after 30 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's and the shipping for the replacement item.



©March 2022 Athena's Home Novelties, Inc. Woonsocket RI 02895 www.athenashn.com 1-877-ATHENAS

Operating

ON/OFF: Press and hold for 3 seconds to start and initiate the 1st speed, press and hold for 3 seconds to stop. Tap the button to adjust speed and tempo of the toy.

Vibration and Pulsation: Tap the On/Off for the 4 additional settings of vibration. Each tap will cycle to the next vibration level of intensity.





This toy comes partially charged. You may choose to fully charge prior to first use. Unscrew the looped tip from the slim long base. Screw the charging cord cable securely into the slim base and connect the other end of the charging cord cable to the USB port of your computer or other power source.

The indicator light will glow red when charging and become green when fully charged. Unplug both ends of the charging cord when the light remains on (solid) and fully charged. There is no danger of battery damage from overcharging. We do, however, recommend not to charge for long, extended periods of time. Screw the looped tip back onto the slim base.

We recommend fully charging your product once every 6 months. Only use the cord supplied with this product or an Athena's authorized replacement cord.

Charge time: 1.5 hours, Run time low speed: 60 minutes, Run time high speed: 40 minutes.