

Come Full Circle

SKU 3558



Something will stir from deep within you when pleasure *Comes Full Circle*. Experience a pyramid of pleasure fingers bringing you to orgasm in a distinctively different way. Two pleasure prongs spin round and round, firmly kneading the sensitive flesh of the clitoris with an exquisite massage. The other prong radiates 9 different patterns of vibration and pulsation for a variety of astounding sensations. The easy-to-hold, ergonomic handle makes it easy to experiment with different positions and pressure. The firm handle has even more to offer! Insert it for a rumbly rush of intensity! Indulge yourself and *Come Full Circle* in a bubble bath or throw your head back between the sheets!


FEATURES

5 year warranty
Rechargeable - Magnetic USB cable included.

Silicone with ABS plastic trim
Latex and Phthalate free
Not for use with silicone lubricants
Waterproof and submersible
Provides G-spot stimulation

Total length: 7.59"
Insertable length: 4.18"
Handle width: 1.47"

Charge time: 2 hours
Run time: 50 minutes on high
Run time: 85 minutes on low



Cleaning

Always clean product before every use, and clean after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-2762).

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer SKU 5701. Not for use with silicone lubricants. You can find additional lubrication options on our web site or in our online catalog.

To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Do not store products near extreme cold or heat. Store in a cool, dry location. Store products separately as different materials may react with each other. Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

Caution: For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty

All sales are final due to the intimate nature of our products. No cash refunds will be given. This motorized product is guaranteed for 5 years for a replacement of the exact item. If you purchased this item at a party and need a replacement, please contact your Goddess or Adonis directly. If you purchased this product on the Athena's website and need a replacement, call (877)-ATHENAS or email our Customer Care Liaison at customerservice@athenashn.com.



© May 2023
Athena's Home Novelties, Inc.
Woonsocket RI 02895

www.athenashn.com
1-877-ATHENAS

Charging


This toy arrives with a low partial charge. Charge fully before first use. Full charging will take about 2 hours.

Connect the USB plug into a power source and align the other end of the charger with the toy's 2 magnetic charging pins, located at the front of the toy under the rotating fingers.

The indicator light will flash while device is charging and turn solid when fully charged. There is no danger of battery damage by overcharging but its recommended not to overcharge for long periods of time. Remove cord prior to operating *Come Full Circle*

Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Only use the cord supplied with this product or an Athena's authorized replacement cord.

Charge time: 2 hours
Run time: 50 minutes on high
Run time: 85 minutes on low



Control Panel



OPERATING:

This dual vibrator operates with a 2-button panel located on the back of the main shaft handle. Each button controls a separate motor with its own ON/OFF function. The bottom button controls the vibration in the handle while the top button controls the prongs rotation and vibration in the head.

Prong Functions: Press the top button for 3 seconds to turn on the rotating function in the head. The light will go on and rotating will begin. Two fingers twirl, one vibrates. Tap to cycle through 9 speeds and functions of prong rotation. Press the button for 3 seconds to turn this motor off.

G-spot Handle Functions: Press the bottom button for 3 seconds to turn on the vibration in the handle. The light will go on and the motor will begin in its first lowest speed. Tap to cycle through a total of 9 speeds and rhythms. Press the button again for at least 2 seconds to turn this motor off.