


# Turned On (the rabbit reimagined)

# **Operating Instructions**

SKU 3580

Considered among the most iconic sex toy designs, rabbit vibes have produced billions of orgasms world wide. Crafted of body-safe silicone, Turned On is a rabbit reimagined. The smooth, curved shaft places fulfilling climax inducing pressure internally. But wait, this rabbit has a new trick up its sleeve! Within the tip, a trio of beads turn round 'n round, massaging the G-Spot, literally giving this classic vibe a whole new spin! Externally, the ear-resistible rabbit shaped stimulator nestles around the clitoris. The flexible ears flutter on either side! The firm nub of the rounded rabbit head covers more erotic real estate with a rumbling buzz if desired! 10 vibrating options and 3 rotating bead speeds allow for a customizable experience. Wet and wild adventures await as this vibe is fully waterproof! Rabbit connoisseurs and those new to pleasure devices will feel hare-raising happiness with this inventive adaptation!



#### **FEATURES**

- 5 year warranty
- Rechargeable Magnetic USB cable included.
- Pleasure Beads and Toy: Independent Motors
- Silicone with ABS plastic detail
- Latex and Phthalate free
- Not for use with silicone lubricants
- Waterproof
- Provides G-spot stimulation

ON (STANDBY) / OFF

- Total length: 7.77"
- Insertable length: 4.75"
- Width: 1.72"
- Charge time: 2 hours
- Run time: 50 minutes on high
- Run time: 60 minutes on low

# ON (STANDBY) Pleasure Bead Speed /OFF ON (STANDBY) Toy 10 Speeds /OFF

# Operating:

This dual vibrator operates with a 3-button panel located under the rabbit of the main shaft handle.

Press the middle button for 3 seconds to turn the toy on. The button will light up and the motors will be in standby mode.

**Toy Speeds:** Once the toy is in standby, tap the bottom button to engage vibration in the bunny shaft. It will begin at its lowest speed. Tap again to cycle through 9 additional vibrating speeds and rhythms. Press the button for 3 seconds to return to standby.

**Pleasure Bead Speeds:** Once the toy is in standby, tap the top button to engage bead rotation in the main shaft. It will begin at its lowest speed. Tap again to cycle through the additional 2 speeds. Press the button for 3 seconds to return to standby

To turn the toy off, press the middle button for 3 seconds. The light will turn off and both motors will cease.

Caution: Continuous constant use of the vibrator's motor may create excessive heat. If your vibrator feels too hot, switch it off and allow it to cool before continuing use.

# Charging

This toy arrives with a partial charge. Charge fully before first use. Full charging will take about 2 hours.

Connect the USB plug into a power source and align the other end of the charger with the toy's 2 magnetic charging dots, located at the back of the toy above the metallic trim.

The indicator light will flash while device is charging and turn solid when fully charged. There is no danger of battery damage by overcharging but its recommended not to overcharge for extended periods of time. Remove cord prior to operating *Turned On*.

Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Only use the cord supplied with this product or an Athena's authorized replacement cord.



# Cleaning

Always clean product before and after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-2762).

### Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer SKU 5701. Not for use with silicone lubricants. You can find additional lubrication options on our web site or in our online catalog.

# To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Do not store products near extreme cold or heat. Store in a cool, dry location. Store products separately as different materials may react with each other. Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

Caution: For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

## Warranty

All sales are final due to the intimate nature of our products. *Turned On* is guaranteed for 5 years for a replacement of the exact item. Please reference our digital catalog or website shopping cart for individual extended product warranties for many of our motorized items. Athena's warranty covers the pleasure device only. No incidental or consequential damages resulting from the use of this product are warrantied. No refunds will be given. If you receive a broken product or if your product breaks please contact your Goddess or Adonis if purchased at a party, or our Customer Care Liaison if purchased on our website, for instructions on how to receive a replacement. Our Customer Care Liaison can be reached by calling (877) ATHENAS or Email to: customerservice@athenashn.com.

© May 2024 • Athena's Home Novelties, Inc. Woonsocket RI 02895 • 1-877-ATHENAS